



Part No.

UP30A-XAX-XXX
UP30A-XFX-XXX
UP30A-XSX-XXX
UP30S-XSX-XXX

Instructions

EN INSTRUCTIONS



PIVOT
UNIVERSAL PUMP

3" DOUBLE DIAPHRAGM PUMP UP30 (1000 l/min-264 gal/min)

2025_10_29-10:15

TECHNICAL DATA

The 3" (76 mm) air operated double diaphragm pumps, made of cast metal, offer a wide range of construction materials and porting configurations. Their design ensures high abrasion resistance for abrasive media and low flow resistance. Available with central threaded or flanged inlet and outlet ports, the pumps feature 180° rotating manifolds for maximum installation versatility.



Non contractual pictures.

Aluminium version

MAIN APPLICATIONS

- CERAMIC & PORCELAIN
- PAINT & VARNISH INDUSTRY
- OIL & GAS / PETROCHEMICAL
- WASTE WATER / WATER TREATMENT
- MARINE & SHIPBUILDING
- FILTER PRESS
- MINING & CONSTRUCTION
- CHEMICAL / PROCESSING
- PULP AND PAPER / CARDBOARD

TECHNICAL DATA

UP30 METALLIC PUMPS

Pressure Ratio	1:1	
Maximum Free Delivery	1.000 l/min (264 US gal/min)	
Air pressure range	1,5 to 8 bar (20 to 120 psi)	
Solids in suspension, Max. size	12,7 mm (1/2")	
Max dry suction lift	6 m (19.7')	
Max wet suction lift	8 m (26')	
Displacement per cycle*	10 l (2.6 gal)	
Fluid inlet/outlet ports	3" NPT (F) Threaded 3" BSP (F) Threaded 3" ANSI/DIN Flanged	
Air Inlet Port	3/4" NPT (F)	
Air Exhaust Port	1 1/2" NPT (F)	
Sound level	83 dB (A) @50 cycles/min @5 bar (70 psi)	
Material and weight: Central Body/ Fluid Chamber & Manifolds		
· Aluminium / Aluminium	Threaded 64 kg (141 lb)	Flanged 71 kg (156.5 lb)
· Aluminium / Ductile Iron	109 kg (240 lb)	116 kg (256 lb)
· Aluminium / 316 SS	118 kg (260 lb)	125 kg (275.6 lb)
· 316 SS / 316 SS	140 kg (308.6 lb)	147 kg (324 lb)

* Delivery per cycle depends on the diaphragm materials, air inlet pressure and fluid viscosity.


PUMP NOMENCLATURE

Examples: UP30A-XXX-XXX
UE30A-XXX-XXX-X


UP30X		XXX			XXX			X
PUMP TYPE	AIR MOTOR	HOUSINGS			WETTED PARTS			ACCESSORIES
1 Pump Type & Size	2 Central Body & Air Chambers	3 Fluid Ports / Location	4 Fluid Chambers & Manifolds	5 Hardware Bolts	6 Valve Seats	7 Valve Balls	8 Diaphragms Type & Material	9 Accessories (UE pumps only)
UP30 Universal Pump (Bolted) UE30 Universal Pump (Bolted) with electronic interface	ATEX Certified A = Aluminium S = AISI 316 Stainless Steel (only for pumps with Stainless Steel Fluid Chambers & Manifolds)	B = 3" BSP Threaded Ports / Centre Horizontal C = 3" ANSI/DIN Flanged Ports / Centre Horizontal N = 3" NPTF Threaded Ports / Centre Horizontal	ATEX Certified A = Aluminium F = Ductile Iron S = AISI 316 Stainless Steel	C = Carbon Steel S = Stainless Steel	A = Aluminium D = AISI 440 Hardened Stainless Steel H = TPE (Hytrell®) M = TPV (Santoprene®) N = Nitrile (Buna-N) S = AISI 316 Stainless Steel T = PTFE (Teflon®) V = FKM (Viton®)	H = TPE (Hytrell®) M = TPV (Santoprene®) N = Nitrile (Buna-N) S = AISI 316 Stainless Steel T = PTFE (Teflon®) V = FKM (Viton®)	Conventional A = TPV (Santoprene®) C = TPE (Hytrell®) G = Nitrile (Buna-N) V = FKM (Viton®) Two-piece Z = PTFE (Teflon®) with TPV (Santoprene®) backer	A = Diaphragm leak detectors B = Diaphragm leak detectors (ATEX) C = Stroke sensor D = Stroke sensor (PLC) E = Stroke sensor (ATEX) F = Diaphragm leak detectors + Stroke sensor G = Diaphragm leak detectors + Stroke sensor (PLC) H = Diaphragm leak detectors + Stroke sensor (ATEX)

Viton® & Teflon® is a registered trademark of the Chemours Company, Santoprene® and Hytrell® is a registered trademark of the Celanese Corporation, L.P. Kynar® is a registered trademark of Arkema, Inc.


Aluminium flanged pumps




Aluminium threaded pumps



Stainless Steel flanged pumps





Stainless steel threaded pumps




DIMENSIONS (mm)	A	B	C	D	E	F	G	H	I	J	K	L	M	N	R	S1 (DIN)	S2 (ANSI)	T1 (DIN)	T2 (ANSI)
UP30 FLANGED	575	905	579	183	353	436	290	140	105	805	536	307	257	15	200	160	152,4	21	21
UP30 THREADED	575	820	543	183	353	436	290	87	61	761	500	307	257	15	-	-	-	-	-

DIMENSIONS (inches)	A	B	C	D	E	F	G	H	I	J	K	L	M	N	R	S1 (DIN)	S2 (ANSI)	T1 (DIN)	T2 (ANSI)
UP30 FLANGED	22.64	35.63	22.80	7.21	13.90	17.17	11.42	5.51	4.13	31.69	21.10	12.09	10.12	0.59	7.87	6.30	6	0.83	0.83
UP30 THREADED	22.64	32.28	21.38	7.21	13.90	17.17	11.42	3.43	2.40	29.96	19.69	12.09	10.12	0.59	-	-	-	-	-




AVAILABLE VERSIONS

FLANGED PUMPS



THREADED PUMPS





Product pictures and specifications are subject to change without prior notice.

The English version is a translation of the original document in Spanish. In case of a discrepancy, the original will prevail.

EQUIPMENT MISUSE



- This equipment is for professional use only.
- Do not tamper the equipment.
- Use the equipment only for its intended purpose.
- Use only original replacement parts from Samoa Industrial, S.A.
- Install and use the pump following all local and national regulations including all health and safety laws and regulations.
- Avoid unnecessary damage to the pump. Do not allow the pump to run for long periods of time without fluid (dry). Disconnect the pump from the air line when the system is idle for long periods of time.

CHEMICAL COMPATIBILITIES AND TEMPERATURE LIMITS



- Chemical compatibility can change with temperature and concentration of chemicals within the fluids being pumped, discharged or circulated. For specific fluid compatibility, consult the chemical manufacturer.
- Maximum temperature limits are based upon mechanical stress only. Certain chemicals will significantly reduce maximum safe operating temperatures. Consult the chemical manufacturer for temperature limits.
- Fluids not compatible with the pump materials can cause damage to the pump and may cause serious personal injuries. Always consult your authorized Samoa supplier if you have questions regarding the pump and fluid compatibility.
- Do not exceed material temperature limits:

MATERIAL	TEMPERATURE RANGE
PTFE	-10 °C / +107 °C / -14 °F / +225 °F
NBR	-23 °C / +82 °C / -10 °F / +180 °F
Acetal	-40 °C / +120 °C / -40 °F / +250 °F
Hytrel®	-29 °C / +104 °C / -20 °F / +220 °F
Neoprene	-18 °C / +93 °C / 0 °F - 200 °F
Santoprene®	-40 °C / +135 °C / -40 °F / +275 °F
Viton®	-40 °C / +177 °C / -40 °F / +350 °F
Polypropylene	0 °C / +65 °C / +32 °F / +150 °F

SAFETY MEASURES



- Ensure that operators using this equipment are trained on the operation, the product and its limitations.
- Use safety equipment as required.
- Do not use a model with aluminium wetted parts to pump fluids for human consumption, there is a possibility of trace contamination of lead.
- Do not exceed the air maximum pressure. Make sure that hoses and other components are rated for the pump maximum working pressure. Check all hoses for damage or wear.
- Never use a pump that leaks, that is damaged, that is corroded or otherwise it may lack the capacity to contain the fluid. Frequently check that the bolts on the pump fluid covers are correctly torqued.
- Check the diaphragm conditions. If a diaphragm is broken, the fluid can leak out of the air exhaust and cause personnel injuries or contaminate the environment.
- When handling hazardous fluids, always route the air exhaust into a suitable container and locate it in a safe place. Install a suitable container surrounding the pump to prevent any leaks or spills.

FIRE AND EXPLOSION HAZARD



- Prevent static sparking. If static sparking occurs, fire or explosion could result. Pump, valves, and containers must be properly grounded when handling flammable fluids and whenever discharge of static electricity is a hazard.
- Danger of explosion if 1,1,1-trichloroethane, methylene chloride or other halogenated hydrocarbon solvents are used with wetted parts made from aluminium. It could cause serious injury and property damage. Check the motor section of the pump, fluid covers, manifolds and all wetted parts in order to ensure compatibility before using these solvents.
- In order to avoid hazardous conditions that can cause fire or explosion all label and marking material must be cleaned to enable proper reading.

DESCRIPTION

Air operated double diaphragm pumps are air-powered, reciprocating positive displacement pumps with two pumping chambers. Two diaphragms, centrally located in the chambers, separate the compressed air (dry side) from the fluid being pumped (wet side). A shaft transmits the reciprocating motion of one diaphragm to the other. A directional


valve alternatively distributes the air from one chamber to the other; thus a reciprocating movement of the diaphragms is created. With each stroke, fluid is discharged by one of the diaphragms whilst the opposite diaphragm sucks new fluid into the expanding chamber. Check valves, two on the discharge side and two on the suction side, control and direct the fluid flow.

INSTALLATION

RECOMMENDATIONS

- Install the pump as close as possible to the fluid being pumped to minimise the suction head.
- For the ease of operation and service, install the pump so there is enough space around it.
- If the pump is installed in a place where fluid leakage can cause an environmental impact, the exhaust should be directed to a place where it can be contained.
- When installing the pump in its place, use brackets to secure its base.
- Fasten all bolts with the torques contained in this manual (REPAIR AND MAINTENANCE section). Let the pump running for a whole day. After that, check the torques again.


UP pumps can be installed with flooded suction, suction lift or submerged in the fluid pumped. The figure below shows the recommended configuration for the pump installation.



AIR EXHAUST DISPOSAL

WARNING

- Remove the pump air muffler.
- Connect a hose with a 1 1/2" NPT thread to the new exhaust port and install the muffler at the end of the hose.
- Be sure the air exhaust is directed to a safe place.



AIR CONNECTION

WARNING

- To ensure that the air flow is sufficient to meet the pump demand, the air pipe diameter must be equal to the pump air inlet.
- Air treatment equipment must be dimensioned to meet pump air demand. It must be installed as close as possible to the pump unit.
- Using air quick couplers to connect the air hoses facilitates pump maintenance.

This pump is self-priming. To prime it the first time, you must connect the air pump supply to a low pressure using the pressure regulators while keeping the outlet valve open.

When fluid begins to flow from the pump outlet, the pump is primed. For regulation of fluid pressure, the unit must be supplied with an air pressure between 1,5 and 8 bar (20 and 120 psi). Adjust the discharge valve on the discharge side to control flow. For the performance characteristics of the pump see the capacity curve.

STOPPING THE PUMP FOR MAINTENANCE TASKS

- Shut off the air supply to the pump.
- Check that the air valve is closed.
- Close the discharge valve and the suction valve. Open inlet and outlet drain valves if installed.
- Open the air valve of the pump, start up the pump and flush the remaining fluid.
- Close the air valve.
- Maintenance can be started after ensuring that the pump is turned off and the pressure is released.
- Unground the pump.

GROUNDING THE PUMP




WARNING: If the pump operates ungrounded or with an incorrect connection, friction between parts and fluid abrasion can generate static electricity. Depending on the fluid pumped and the installation environment, static electricity can cause either fire or electric shock.

When installing the pump, be sure to perform grounding in the specified location if required.

Also connect ground wires for the auxiliary equipment and piping. Use a grounding cable of at least 12 AWG (2.0 mm).

POSITION OF THE
GROUND WIRE



ATEX CERTIFIED PUMP

If your pump is ATEX certified, a specific Atex manual is included. Read this manual before operating the pump.

If the symbol "Ex" is in the pump nameplate it can be used in the potentially explosive atmospheres indicated areas (details on the ATEX manual).



TROUBLESHOOTING

CAUSE	RECOMMENDED MEASURE
THE PUMP DOES NOT WORK	
Discharge valve on the discharge side is not open.	Open the valve on the discharge side.
No air supply.	Turn on the compressor and open the air valve and air regulator.
Low air supply pressure.	Check the compressor and the air line configuration.
Air leaks in connecting elements.	Check the connection elements and screws tightening.
Air pipes or additional equipment is clogged.	Check and clean the air line.
Pump exhaust port (muffler) is clogged.	Check and clean the exhaust port and muffler.
Fluid pipe is clogged.	Check and clean the fluid line.
Clogged pump.	Remove, inspect and clean the pump.

THE PUMP RUNS BUT NO FLUID COMES OUT	
Valve on the suction side is not open.	Open the valve on the suction side.
Too much suction or discharge height.	Reduce lengths/heights of suction and discharge pipes.
Fluid pipe on the discharge side (including the filter) is clogged.	Check and clean the fluid line.
Clogged pump.	Dismantle the pump, check and clean.
Balls and/or ball seats are worn or damaged.	Inspect and replace parts.

DECREASING FLOW	
Low air supply.	Check the compressor and the air line configuration.
Air line or peripheral equipment is clogged.	Check and clean the air line.
Valve on the discharge side will not open normally.	Adjust the discharge valve on the discharge side.
Air mixes with the fluid.	Replenish with fluid and check the pipe configuration on the suction side.
Pump is vibrating.	Adjust air supply pressure and discharge pressure. Reduce the inlet valve flow to adjust the pressure and fluid volume. Securely fix the pump with the bracket to the base.
Ice formation in the air exhaust.	Remove ice from the air bypass valve and check and clean the air filter. Use a pipe in the air exhaust so there is no ice formation in the muffler (see AIR EXHAUST DISPOSAL).
Fluid line (including the filter) is clogged.	Check and clean the fluid pipe and strainer.
Pump exhaust port (muffler) is clogged.	Check and clean the exhaust port and muffler.
Clogged pump.	Remove, inspect and clean the pump body.

THE FLUID COMES OUT WITH AIR BUBBLES	
Damaged diaphragm.	Replace diaphragm.
Loose or broken suction hose.	Tighten or replace.

TORQUE SPECIFICATIONS



For proper pump operation and to prevent accidents, you must periodically review the torques of the diaphragms covers and the directional valve. The table shows the appropriate torques for this purpose:

CAUTION! DO NOT OVERTIGHTEN FASTENERS. SHUT OFF THE AIR SUPPLY BEFORE ANY INTERVENTION. BE AWARE OF A POSSIBLE FLUID LEAKAGE INSIDE THE PUMP.

TIGHTENING TORQUES UP30

Torques UP30	Fluid Chamber (For Diaphragms Santoprene - Hytrel - PTFE)	160 N·m (118 ft.lbs)
	Fluid Chamber (For diaphragms NBR - FKM)	120 N·m (88.5 ft.lbs)
	Manifolds	120 N·m (88.5 ft.lbs)
	Fluid Piston	150 N·m (111 ft.lbs)
	Air Chamber - Central Body	50 N·m (37 ft.lbs)
	Air Motor Cover	15 N·m (11 ft.lbs)

ATTENTION! TIGHTENING SEQUENCE



AIR VALVE



1. Remove the six screw of the "aircap".
2. Remove the "aircap" and pull out the air valve.
3. Place the bottom gasket in the new air valve.
4. Insert the new air valve.
5. Place the "aircap" with the gaskets in its housing.
6. Tighten the screws.

AIR SENSOR

The air sensors are on the central body.
First follow the procedure for "Replacing diaphragms".


Once the fluid covers are removed proceed as follows:

1. Remove the two screws that secure the air sensor to the top.
2. Remove all components of the sensor. Clean the area.
3. Introduce new components in the order shown.
4. Fit the remaining components in reverse order. Fit the sensor cover and tighten the screws.
5. Repeat the process on the opposite side of the pump.



REPAIR AND MAINTENANCE

SHAFT, BUSHINGS AND SEALS




Follow the procedure for replacing the diaphragm, then proceed as follows:

1. Remove air cover screws.
2. Lift away the air cover from the central body.
3. Now the bushing and seals can be replaced. Clean the area and apply lubricate.
4. Fit the remaining components in reverse order.
5. Repeat the process on the opposite side of the pump.

BALLS AND SEATS

Before opening the pump follow the steps in STOPPING THE PUMP FOR MAINTENANCE TASKS.

1. Remove the inlet and outlet manifolds.
 2. Install a new set of balls or seats or according to these assembly drawings.
Tighten the manifold bolts.
- IMPORTANT:** Gradually tighten the manifold with the bolts before proceeding with the final tightening.



IMPORTANT:

Soft seats (NBR, Hytrel® and Santoprene®) don't need extra seals and the seats can be assembled upside down.
Hard seats (PP, POM, PVDF, aluminum, stainless steel), use additional o-rings for sealing.
Balls must be always assembled over the seat.

IMPORTANT:

If the pump maintenance involves disassembling the manifolds and the pump is configured with PTFE o-rings (white colour), they must be replaced by new ones in order to avoid fluid leakages.

DIAPHRAGM

Before opening the pump follow the steps in STOPPING THE PUMP FOR MAINTENANCE TASKS.

1. Unscrew the outlet manifold and lift it. Remove the valve seats, o-ring (if applicable) and balls.
2. Turn the pump upside down to remove the inlet manifold screws.
Remove the seats, seals (if necessary) and balls.
3. Unscrew the fluid cover screws and remove it by gently pulling back.

NOTE:

Use a torque wrench to tighten the screws (see torques table).

4. Remove the used diaphragm. For one-piece diaphragms unscrew by pulling with the hand. In case of two-piece diaphragms (diaphragm with outer piston) use an adjustable wrench and apply corresponding torque.
5. Repeat for opposite side.

INSTALLING NEW DIAPHRAGMS



CAUTION: Follow next procedure to ensure the diaphragms are correctly installed. Otherwise diaphragms may be damaged, causing fluid leaks or premature diaphragm failure.


Please note this recommendation if you notice leaks after installing the diaphragm.



CAUTION!



1. Correct assembly of the diaphragm before the diaphragm cover assembly.



2. Incorrect assembly of the diaphragm.
Possible damage when assembling the diaphragm cover.

EC CONFORMITY DECLARATION



SAMOA INDUSTRIAL, S.A., Pol. Ind. Porceyo, I-14 · Camino del Fontán,
831 · 33392 - Gijón - Spain, declares that the product(s):
UP30A-XAX-XXX, UP30A-XFX-XXX
UP30A-XSX-XXX, UP30S-XSX-XXX
conform(s) with the EU Directive(s):
2006/42/EC

For SAMOA INDUSTRIAL, S.A.

Pedro E. Prallong Álvarez
Production Director

2025_10_29-10:15



www.samoaindustrial.com

